

CF70

Honda NC750X

2016-

Kit for the left side

No.	Description	Cat.no.	Pcs
1	crash frame		1
2	silentblock	X34	1
3	nut M8	813	1
4	3M tape		1
5	sticker RDmoto		1

Kit for the right side

No.	Description	Cat.no.	Pcs
1	crash frame		1
2	silentblock	X34	1
3	nut M8	813	1
4	screw M6x25mm	874	1
5	pad M6 - flat	947	2
6	nut M6 – insurance	948	1
7	3M tape		1
8	sticker RDmoto		1

Installation :

1. Remove the bottom plastic under the engine
2. To the crash frames mount siding (item 2) and nuts (item 3)
3. Crash frames for the right and left side mount under the original screws (on the pictures), but do not tighten the screws
4. In front of the light connect crash frames by the screw (item 4) with pads (item 5) and nut (item 6)
5. Now you can tighten all the screws and mount back bottom plastic under the engine

The right side:



The left side:

